

# Over 50 years

The longest established cleanroom company in the UK



## BASSAIRE

IS CLEAN AIR

## Case Study: Baxter Healthcare (Christie unit)

### ISO class 7 compounding suite with ISO class 8 background areas

This facility comprised of an ISO 7 cleanroom suite housing a Compounding room where rapid gassing isolators carried out the compounding of quick prescription cytotoxic drugs. The surrounding back up areas, comprising of labels/docs/release, preparation and change rooms were all to ISO 8.

In addition to the cleanroom construction, Bassaire were involved totally in the construction of the Administration support areas required to support the cleanroom, which are generally comprised of standard office partitioning, electrics and HVAC.



Some major design consideration of this facility were:

- The full walk on ceiling over the cleanroom suite, offering excellent maintenance access to routine items such as light fittings, plant items, etc. which allows maintenance to continue without any impact on the operation of the cleanroom, and
- The provision of essential electrical supplies should the mains power supply to the facility be lost. This was provided by a stand by generator and UPS back up.

### Other products and services

Bassaire has over fifty years experience in the design, manufacture, installation and maintenance of cleanrooms and clean air products.



cleanrooms



laboratories



clean air products



servicing

ds-34402-v2

[www.bassaire.co.uk](http://www.bassaire.co.uk)

www.bassaire.co.uk | Tel: +44 (0) 1489 885111 | Fax: +44 (0) 1489 885211 | Email: sales@bassaire.co.uk

Bassaire Limited · Duncan Road · Park Gate · Southampton · Hampshire · SO31 1ZS · England

Registered in England: 2107555 · © Bassaire Limited